# Turn Camera on

To delete video press garbage can

Press to play video and stop video

To start and stop recording push the red button

The +and - zoom in and out

When watching a video the + and - control sound volume

Push to start and stop viewing video

To download video plug USB port into computer then turn camera on

ultra

Press left/right buttons to view previous/next

Attachments

Pixels.wmv

Flip1.wmv